

# Cleaning Instructions

## PRODUCT: Rootz Cup Coffee Machine



### Cleaning:

- Empty the drip tray, the drip base and the used capsule container.
- Remove the water tank and clean all parts with an ordinary dishwashing detergent and rinse with warm potable water.
- Dry with a fresh and clean towel, cloth or paper and reassemble all parts.
- Clean the coffee outlet and the outside of the machine regularly with a damp cloth.

### Descaling procedure using white vinegar:

The coffee machine must be descaled regularly. The frequency of descaling depends on usage and the hardness of the water in your area.

1. Remove the capsule and close the lever.
  2. Empty the drip tray and used capsule container.
  3. Fill the tank with water up to 3/4 of the maximum level.
  4. Now add white vinegar (8% acetic acid) to the MAX level.
  5. Place a container (min. volume 500ml) under the coffee outlet.
  6. Press the Espresso or Lungo button. The water will flow now.
  7. Repeat step 6 until the water tank is empty.
  8. Empty and rinse the water tank. Fill it with potable water.
  9. When ready, repeat step 5, 6 and 7 to now rinse the machine.
- Repeat twice until there is no more smell of vinegar.
10. The machine is now ready for use.